

## LED Par Light User Manual

### Attention

1. Please read these operating instructions carefully to familiarize you with basic operations of this unit Before use
2. Without permitted is prohibited to spread the contents of this manual to others
3. This manual is only to provide related information, and the contents of this manual will be changed at any time without notice

### Inspection

In order to use the product securely and properly, please read the manual before using and follow the instructions strictly to prevent personal safety trouble and product damage caused by misuse. Take care of the product, check the possibility of the product damage caused by transportation and check all the listed items are present upon receipt of the product:

LED Par Light 1 Use Manual 1 Power cable 1

### Installation

1. Make sure there is no flammable or explosive subjects within min 1.5 meter nearby the installation.
2. Before installation, please check and make sure the power supply voltage meet request of the system.
3. Please check ventilation and fans or exhaust passages are cleared. T

### Installation

Light Source	1.5W
Power Supply	100-240V/50-60HZ
Rated Power	80-90W
Control Mode	Auto/Sound/DMX/Master-slave
DMX Channel	8

### LED display menu function

No.	Display	Function
1	D0001	8 channel DMX address setting, (001—512) Press B, C to change address No.
2	Cc00	7 color jump change, (01—99) Press B, C to change jump change speed
3	Cp00	7 color pulse change, gradual change, (01—99) Press B, C to change pulse, gradual change speed
4	De00	7 color combination change, (01—99) Press B, C to change combination change speed
5	Be00	7 color sound control
6	R255	Red dimming, (000—255)
7	G145	Green dimming, (000—145)
8	B135	Blue dimming, (000—135)
9	W130	White dimming, (000—130)

### DMX control

CH	Function	Instruction
1	Master dimming	R, G, B, W dimming From dark to bright
2	Strobe	Strobe from slow to fast
3	Function option	0—50 : DMX 8CH control ; 51 — 100 : jump change ; 101—150 : gradual change ; 151—200 : pulse change ; 201—255 : sound control
4	Function speed	From slow to fast
5	Red dimming	From dark to bright
6	Green dimming	From dark to bright
7	Blue dimming	From dark to bright
8	White dimming	From dark to bright

## LED Par Light User Manual

### Attention

1. Please read these operating instructions carefully to familiarize you with basic operations of this unit Before use
2. Without permitted is prohibited to spread the contents of this manual to others
3. This manual is only to provide related information, and the contents of this manual will be changed at any time without notice

### Inspection

In order to use the product securely and properly, please read the manual before using and follow the instructions strictly to prevent personal safety trouble and product damage caused by misuse. Take care of the product, check the possibility of the product damage caused by transportation and check all the listed items are present upon receipt of the product:

LED Par Light 1 Use Manual 1 Power cable 1

### Installation

1. Make sure there is no flammable or explosive subjects within min 1.5 meter nearby the installation.
2. Before installation, please check and make sure the power supply voltage meet request of the system.
3. Please check ventilation and fans or exhaust passages are cleared. T

### Installation

Light Source	1.5W
Power Supply	100-240V/50-60HZ
Rated Power	80-90W
Control Mode	Auto/Sound/DMX/Master-slave
DMX Channel	8

### LED display menu function

No.	Display	Function
1	D0001	8 channel DMX address setting, (001—512) Press B, C to change address No.
2	Cc00	7 color jump change, (01—99) Press B, C to change jump change speed
3	Cp00	7 color pulse change, gradual change, (01—99) Press B, C to change pulse, gradual change speed
4	De00	7 color combination change, (01—99) Press B, C to change combination change speed
5	Be00	7 color sound control
6	R255	Red dimming, (000—255)
7	G145	Green dimming, (000—145)
8	B135	Blue dimming, (000—135)
9	W130	White dimming, (000—130)

### DMX control

CH	Function	Instruction
1	Master dimming	R, G, B, W dimming From dark to bright
2	Strobe	Strobe from slow to fast
3	Function option	0—50 : DMX 8CH control ; 51 — 100 : jump change ; 101—150 : gradual change ; 151—200 : pulse change ; 201—255 : sound control
4	Function speed	From slow to fast
5	Red dimming	From dark to bright
6	Green dimming	From dark to bright
7	Blue dimming	From dark to bright
8	White dimming	From dark to bright