# JLPOW COB Par Light
## User Manual

Thank you for choosing JLPOW COB par light which features RGB colors and multi-function. Whenever you go dancing or to a show, it can fuel your passion and create the best visual atmosphere. The manual describes how to use it and the safety issues. Please read it carefully and keep it as your reference.

## A. Specifications:

- Power Voltage: AC100V-240V / 50-60 Hz
- Power Consumption: 15W
- LED: 1 * 15W 3 in 1 LED (Red / Green / Blue)
- Mode: Auto / Voice-activated / DMX / Master-slave
- Channel: **6**CH
- Beam Angle: Approx. 25°
- Dimming: 0% - 100%
- LED Life: 10000 Hours
- Connector: 3 Pin XLR
- Shell Material: ABS Plastic
- Product Weight: 0.97lb / 439g
- Size: 4.7*4.7 *3.5 inch / 11.93*11.93*8.9 cm

## B. Package Includes

1 x Par Light        1 x Remote Control        1 x User Manual

## D. DMX Control: 6 Channels

| Channel | Value | Functional Description |
|---|---|---|
| CH1 | 0-255 | Master Dimming (CH5-CH6) |
| CH2 | 0-255 | Red Light – From Dark to Bright |
| CH3 | 0-255 | Green Light - From Dark to Bright |
| CH4 | 0-255 | Blue Light - From Dark to Bright |
| CH5 | 0-5 | Need to Use with CH1-CH4 |
| | 6-255 | Strobe Mode, From Slow to Fast |
| CH6 | 0-50 | OFF |
| | 51-90 | Jump Mode |
| | 91-130 | Color Selection |
| | 131-170 | Gradual Mode |
| | 171-210 | Auto Mode |
| | 211-255 | Sound Activated Mode |

## C. Operating Instructions:

Menu - Mode Selection
Up - Value Added
Down - Value Subtracted
Enter - Confirmation

| Menu | Numerical | Description |
|---|---|---|
| d001 | d001-d512 | DMX Address |
| IP.01 | IP.01- IP.73 | Slave Mode |
| A1.01 | A1.01- A1.07 | Color Selection* |
| A2.00 | A2.00- A2.20 | Jump Mode, Adjust Speed 00-20, press "enter" button to save your settings |
| A3.00 | A3.00- A3.20 | Gradual Mode, Adjust Speed 00-20, press "enter" button to save your settings |
| A4.00 | A4.00- A4.20 | Auto Mode, Adjust Speed 00-20, press "enter" button to save your settings |
| A5.00 | A5.00- A5.20 | Sound Activated Mode, Adjust Sound Sensitivity 00-20, press "enter" button to save your settings |
| FF.00 | FF.00- FF.20 | Strobe Mode, Adjust Speed 00-20 |
| r000 | r000-r255 | Red Brightness(Dark-Bright) |
| G000 | G000- G255 | Green Brightness (Dark-Bright) |
| b000 | b000- b255 | Blue Brightness (Dark-Bright) |

### *Color Selection Details: (A1)

| No. | Color | No. | Color | No. | Color |
|---|---|---|---|---|---|
| A1.01 | Red | A1.02 | Green | A1.03 | Blue |
| A1.04 | Yellow | A1.05 | Purple | A1.06 | Light blue |
| A1.07 | RGB (White) | | | | |

## E. Note

- Please keep it safe from falling and dropping.
- Confirm the supplied voltage is stable and required.
- Indoor use only, please do waterproof measures if outdoor use.
- Keep away from Children. Please do not look at the light directly, in case it might damage the eyes.

## F. Feedback

We appreciate your 5-star feedback and positive comments if you are satisfied with our products! If you have any questions or problems, feel free to contact with **support@jlpow.com.** We take care of every feedback from you, and strive to perfect our product all the times.