

d001	001-512	512Address setting
CHxx	03	3Channel mode
	05	5Channel mode
	12	12Channel mode
Auxx	01	red
	02	green
	03	blue
	04	yellow
	05	white
	06	Color combination
	07	Color combination
	08	Color combination
	09	Color jump
	10	Color gradient
	So01	Voice-activated jump
	So02	Voice-activated strobe
St00	00	Automatic host without strobe
	St01-St16	Automatic host strobe speed from slow to fast
SP00	SP00	Automatic hostAu08 Au09 Au10Speed from slow to fast
	SP16	
r000	r000	Red maximum brightness setting
	r255	
G000	G000	Green maximum brightness setting
	G255	
B000	B000	Blue maximum brightness setting
	B255	
A000	W000	Yellow maximum brightness setting
	W255	
W000	A000	White maximum brightness setting
	A255	
3Channel mode		
1	Dimming	0-255
2	strobe controll	0-255
3	Macro function	0-255
5Channel mode		
1	red dimming	0-255
2	green dimming	0-255
3	blue dimming	0-255
4	yellow dimming	0-255
5	white dimming	0-255
12Channel mode		
1	dimming	0-255
2	strobe controll	0-255
3	red dimming	0-255
4	green dimming	0-255
5	blue dimming	0-255
6	yellow dimming	0-255
7	white dimming	0-255
8	Macro function color jump	0-255
9	Macro function speed of jumping	0-255
10	Macro function color gradient	0-255
11	Macro function speet of gradient	0-255
12	Macro function sound controll	0-255