

14 Channel

Channel	Value	Function
1CH	0-255	Pan
2CH	0-255	Pan Fine
3CH	0-255	Tilt
4CH	0-255	Tilt Fine
5CH	0-255	XY Speed
6CH	0-7	OFF
	8-134	Master Dimmer
	135-239	Strobe from slow to fast
	240-255	Open
7CH	0-255	Red dimmer
8CH	0-255	Green dimmer
9CH	0-255	Blue dimmer
10CH	0-255	White dimmer
11CH	0-7	Mix color depend on 7CH-10CH
	8-231	Macro color
	232-255	Color jumping
12CH	0-255	Color jumping speed
13CH	0-7	Control freely depend on 1CH-12CH
	8-63	Fast running
	64-127	Slow runing
	128-191	Sound 1
	192-255	Sound 2
14CH	150-200	Reset




Please read this manual carefully before operating this product.

MINI-LED-BEWEGLICHER KOPF
Handbuch




IR-RCMOTC-Steuerung

- 1) AN AUS:
- 2) Blinken:
- 3) sparen:
- 4) Auto1: Automatisch laufendes Modell, das die Farbauswahl ermöglicht (R,G,B,W,RG,RB,GB,RGB).
- 5) Auto2: Schneller automatischer Betriebsmodus
- 6) Auto3 : Langsamer automatischer Betriebsmodus
- 7) Manuell: Ermöglicht die zufällige Einstellung der PAN- oder TILT-Position,und zur Farbauswahl (R, G, B, W, RG, RB, GB, RGB).
- 8) Musik 1: Tonmodus 1
- 9) Musik2: Tonmodus 2
- 10) X+, X- : Zum Anpassen der PAN-Position
- 11) Y+, Y- : Zum Anpassen der TILT-Position
- 12) R, G, B, W, RG, RB, GB, RGB



1.ANZEIGE



Menu : Menü : Menü auswählen oder beenden


Up : Parameter erhöhen

Down: Verringerung der parameter

Enter: Bestätigen oder Untermenü aufrufen

1. Die Funktion der Maschine ist die automatische Erkennung des DMX- oder SLAVE-Signals.

2.2.Wenn ein Parameter geändert wird und die “Enter”-Taste gedrückt wird, wird der neue Wert nach der Anzeige “.....” auf der digitalen Röhre gespeichert.



2. DMX

9 Kanal

Channel	Value	Function
1CH	0-255	Pan \X-Achse
2CH	0-255	Neige die Y-Achse
3CH	0-7	AUS
	8-134	Master-Dimmer
	135-239	Strobe von langsam nach schnell
	240-255	Offen
4CH	0-255	Roter Dimmer
5CH	0-255	Grüner Dimmer
6CH	0-255	Blauer Dimmer
7CH	0-255	Weißer Dimmer
8CH	0-255	XY-Geschwindigkeit XY
9CH	150-200	Zurücksetzen

14 Channel

Channel	Value	Function
1CH	0-255	Pan
2CH	0-255	Pan Fine
3CH	0-255	Tilt
4CH	0-255	Tilt Fine
5CH	0-255	XY Speed
6CH	0-7	OFF
	8-134	Master Dimmer
	135-239	Strobe from slow to fast
	240-255	Open
7CH	0-255	Red dimmer
8CH	0-255	Green dimmer
9CH	0-255	Blue dimmer
10CH	0-255	White dimmer
11CH	0-7	Mix color depend on 7CH-10CH
	8-231	Macro color
	232-255	Color jumping
12CH	0-255	Color jumping speed
13CH	0-7	Control freely depend on 1CH-12CH
	8-63	Fast running
	64-127	Slow runing
	128-191	Sound 1
	192-255	Sound 2
14CH	150-200	Reset



Please read this manual carefully before operating this product.

MINI LED MOVING HEAD
User’s Manual




IR remote control

- 1) ON/OFF:
- 2) Flash :
- 3) Save :
- 4) Auto1 : Auto running mode1 which allow to select color (R,G,B,W,RG,RB,GB,RGB).
- 5) Auto2 : Fast auto running mode
- 6) Auto3 : Slow auto running mode
- 7) Manual: Allow to set PAN or TILT position at random, and to select color(R,G,B,W,RG,RB,GB,RGB).
- 8) Music1: Sound mode 1
- 9) Music2: Sound mode 2
- 10) X+ , X- : To adjust PAN position
- 11) Y+ , Y- : To adjust TILT position
- 12) R, G, B, W, RG, RB, GB, RGB:



1. Display



Menu : To select menu or exit

Up : Increase parameter


Down: Decrease parameter

Enter: Confirm or enter submenu

Note

1.The machine have function is that auto recognizing DMX or SLAVE signal.

2.When any parameter is changed and to press the “Enter ” button, the new value is saved after display “- - - -” on digital tube.



2. DMX

9 Channel

Channel	Value	Function
1CH	0-255	Pan
2CH	0-255	Tilt
3CH	0-7	OFF
	8-134	Master Dimmer
	135-239	Strobe from slow to fast
	240-255	Open
4CH	0-255	Red dimmer
5CH	0-255	Green dimmer
6CH	0-255	Blue dimmer
7CH	0-255	White dimmer
8CH	0-255	XY Speed
9CH	150-200	Reset