

DMX CHANNELS Lumeri mini moving head 1.30

<https://www.lumeri.nl/stage-light/moving-heads.html>

9 channel mode

<u>Channel</u>	<u>Value</u>	<u>Function</u>
1	0-255	Pan Running
2	0-255	Tilt Running
3	10-139	Choose Colour
	140-255	Auto change colour(slow to Fast)
4	8-63	Fixed Gobo's
	72-127	Gobo's fixed Patterns
	128-255	Auto change Gobo's(slow to fast)
5	0-255	Strobe (slow to fast)
	140-255	Auto colour change (slow to fast)
6	0-255	Dimmer
7	0-255	Running in Pan & Tilt
8	60-159	Auto mode
	160-255	Sound Mode
9	10-100	Pan Running
	101-200	Tilt Running
	201-249	PanTilt running
	250-255	Reset

11 channel mode

<u>Channel</u>	<u>Value</u>	<u>Function</u>
1	0-255	Pan Running
2	0-255	Panning Fine
3	0-255	Tilt Running
4	0-255	Tilt Fine
5	10-139	Choose colour
	140-255	Auto colour change (slow to fast)
6	8-63	Fixed Gobos
	72-127	Pattern dither
	128-255	Change patterns(slow to fast)
7	0-255	Strobe
8	0-255	Dimmer
9	0-255	Running speed in Pan & Tilt
10	0-59	Function of other channel
	60-159	Auto mode
	160-255	Sound mode
11	10-100	Pan running
	101-200	Tilt running
	201-249	PanTilt running
	250-255	Reset

Voltage AC110-220V, 50/60 Hz

Power consumption 60 Watt

Light source 1Pcs. 30W white led

Gobo's 8

Colours 8

Channels 9 / 11

Operation DMX,Sound,Master/Slave,Auto

Tilt 540 "

Pan 270 "