

DMX CHANNELS Eurolite Led Party

<https://www.steinigke.de/eurolite/>

5 channel mode

Channel	Value	Function
1	000-255	Red (0 – 100%)
2	000-255	Green (0 – 100%)
3	000-255	Blue (0 – 100%)
4	000-255	Dimmer (0 – 100%)
5	000-000	No Function
	001-005	Sound Control
	006-010	No Function
	011-255	Strobe (Increasing)