

DMX CHANNELS Laserworld Model EL-900RGB

[https://www.laserworld.com/en/download-file-43-Laserworld Manual Ecoline Series EL 900RGB web.html](https://www.laserworld.com/en/download-file-43-Laserworld%20Manual%20Ecoline%20Series%20EL%20900RGB%20web.html)

<u>Channel</u>	<u>Value</u>	<u>Function</u>
1 (Mode)	0 - 49	Laser off
	50 - 99	Sound mode
	100 - 149	Automatic mode
	150 - 199	Static patterns of DMX mode
	200 - 255	Dynamic patterns of DMX mode
2	0 - 255	Pattern selection
3	0 - 255	Strobe effect
4 (Color)	0 - 39	White color
	40 - 79	Yellow color
	80 - 119	Purple color
	120 - 159	Cyan color
	160 - 199	Red color
	200 - 239	Green color
	240 - 255	Blue color
5	0 - 255	x axis positioning
6	0 - 255	y axis positioning
7	0 - 255	Scan speed
8	0 - 255	Dynamic patterns speed
9	0 - 255	Zoom