

275W Beam & Spot & Wash Moving Head Lighting

SHEHDS



Maintenance

1. Please keep the light in dryness and avoiding use in wet place.
2. Using intermittently can be extended the life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the crust using organic menstruum for avoid to damaged the product.

Statement

The product has well capability and intact packing when leave factory, All of the user should comply with above warning item and manual, any misuse cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignore the manual.

Please forgive that we will not be notice for technical change

Attention Item


- 1.For guarantee the life of product,please do not put it on the wet place and not use it the place over 40 degree.
- 2.Please don't lay the product on the un-fixable or shakable place.
- 3.Ask for the professional to maintain the product in order to avoid the danger of get an electric shock.
- 4.Power supply should not be changed over +&-10% while the light is using,it will be decreased the life of lamp if the power is too high,but it will be influenced the luminosity if the power is too low.
- 5.After power off,if it is need used again,please cool down over 20 minuter.
- 6.Please look round the manual for ensure the product can be used normally.

Display Control Instruction

Welcome to use our light.The light uses energy-saving LED,long Product life,shockproof,dustproof, DMX receiver and self-running feature, which can produce a variety of vivid lighting effects,easy to operate, suitable for all types of entertainment decoration,architectural lighting industry.

Access control panel functions using the four buttons located directly underneath the LED display on the included wired remote.

BUTTON	FUNCTION
<MENU>	Used to scroll through the current operating mode, as well as back out of the current menu option
<DOWN>	Used to select decreasing advancement in the value
<UP>	Used to select increasing advancement in the value
<ENTER>	Used to select a value and store it to memory



MENU UP DOWN ENTER

The Control Panel shows the current state of the unit. It is used to select the operating mode, as well as the sub-features. For a detailed layout of the control panel functions, please see the "menu map" section on the following page.

Instructions:Press the function key A cycled out the eight different function effects,digital tube first two digits on behalf of which the current function(see menu).The last two digits represent the functions in which the address code or speed parameters.Press the B or C key to modify the parameter values.Press the D key to confirm.

Product Introduction

- * **Power Supply:** AC90--275V,50--60HZ
- * **Power consumption:** 275W
- * **Lights Source:** Bulb
- * **Drive Current:**1500mA
- * **Color Temperature:** 8000k
- * **Beam Angle:** 5-15 Degrees
- * **Color Wheel:**14 kind of colors +white(half-color-effect)
- * **Rainbow Wheel:** Color rainbow effect with variable speed
- * **Prism1:** 8-facet circular prism rotating variable speed
- * **Prism2:** 16-facet circular prism rotating variable speed
- * **Dimmer:** 0-100% mechanic dimmer
- * **Control Modes:**DMX512,Auto Run,Sound Action,Strobe, Stand Alone and Master/Slave,With Rich Advanced Built-in Program
- * **Strobe:** Flash rate 0--25HZ
- * **DMX-Control-channels:**14/16 DMX Channels
- * **Frost:**Soft lights effect
- * **Tilt:** 270° (16bit)
- * **Pan:** 540°(16bit)
- * **Dimmer:** 0-100% mechanic dimmer
- * **Long Lifespan LEDs**(more than 60,000 hours)
- * **Waterproof level:** IP20 Indoor
- * **Ambient temperature:** -20°C ~ 40°C
- * **Cooling System:** Box Heat Conduction
- * **Shell Material:** high temperture resistant plastic
- * **Product Color:** Black
- * **Product Size:** 29x23x50cm
- * **Product Weight:** 13.15kg
- * **Package Size:** 31X25x52cm
- * **Package Weight:** 20kg

- * **Certificate:** CE & ROHS & UL & FCC & EAC & SAA
- * **Warranty:** Within 1 year.[we are free to repair, provide any accessories; or send new products.]
- * **Plug:** To send you to meet the requirements of the plug, EU,US,AU,UK Plug and so on.
- * **Use Of Premises:** Outdoor ,Party,DJ,Bar,Clubs,Hotels,Restaurant, Church,Concert,Stages.

Display Control Instruction

Reverse	Reverse the screen display
Exit	Exit to the main interface
Language	Simplified Chinese or English can be selected
Standard	Address code and some commonly used function settings
Advanced	Main debugging parameter settings at the factory
Info	Information display of errors, software versions, etc.
Program	Manual control operation, or edit user program
Perform	Automatic operation or sound control operation built-in program, user program
Reset	System reset to initial position

DMX Channel Summary-16 Channels Mode

Channel	Function	Value	Function
CH1	X axis	0-255	Pan X axis Fine tuning
CH2	Y axis	0-255	Tilt Y axis Fine tuning
CH3	Level fine-tuning	0-255	1.8°
CH4	Vertical fine-tuning	0-255	1.8°
CH5	XY speed	0-255	0-255 Total dimming
CH6	Effect	0-255	Rainbow Effect
CH7	Strobe	0-255	0 turn off 1-50 turn on 51-240 strobe(from fast to slow) 241-255 turn on
CH8	Dimmer	0-255	0-255 dimming(0-100%)
CH9	Color	0-255	0-127 color optional 128-191 color position flow (from fast to slow) 192-255 color reverse flow (from slow to fast)
CH10	Color Effect	0-255	0 -127 Half color off 128-255 Half color on
CH11	Gobo	0-255	0-255 gobo optional (from fast to slow)
CH12	Gobo shake	0-255	0 on Gobo shake 1-191 Gobo shake (from fast to slow) 192-255 off Gobo shake
CH13	Zoom	0-255	gobo definition from far to near
CH14	Prism	0-255	Prism effect
CH15	Prism rotation	0-255	Prism rotation effect
CH16	reset	0-255	100-105 turn off 200-205 turn on 252-255 reset